



Sign in with your Red Clay Google Account to save your settings and passwords.

Access the Internet through the Chrome Browser.

Access SMART Notebook or PDFs that have been created, opened or shared with the board. View directions on how to share a notebook file with the board.

Directions on how to use the SMART Notebook Player mobile app.

11:36 AM

Wednesday, January 8, 2020

Customize the board's settings like change the wallpaper or update the software.

Sign out of your profile or Clean Up the screen and log out of accounts.

Settings

Files

Apps

Screen Share

Clean Up

Front control panel. See additional image for labels.

Pens with erasers on the ends. Erase with the soft side of your fist too.

Remote behind the board that adjusts the board's height. Nothing should be placed below the board. (i.e. bookshelf)

Sensor that activates the board. Can be turned off through configuration/control panel settings.




Recently accessed websites and files are displayed here.

Recent



Favorites



Favorite websites and files are displayed here.

11:36 AM

Wednesday, January 8, 2020

Star the website or file to move it into your the **Favorites** category.

Create a basic SMART presentation.

Quickly create a Shout It Out! Activity.

Add "apps" to the home screen. The Browser, Player, and kapp Whiteboard are the only SMART apps. Other apps are bookmarks to your favorite websites.

Write on a whiteboard.

Access SMART Notebook or PDFs that have been created, opened, or shared with the board.

Share a Chromebook or iPad screen with the board.

