


CONNECTING PROJECTORS



CONNECTING PROJECTORS

5) Take 3ft audio cable (w/adapter on end) or 6ft audio cable (w/out adapter)and plug single end into the back of the computer's green audio port.

6) Connect red & white audio end into coordinated colored ports near network drop



7) From the remote, select **Menu**.

8) Select Mirror and choose **H&V:Invert**. (This will invert the screen.)

Note: If there is a DVD or a VCR that needs to be connected, unplug the R & W audio cables out of the wall. Connect a R&W&Y audio/video cable into the wall and into the DVD/VCR.

Please explain this to the teacher!