


Chromebook WiFi Access Help

If you are unable to connect your Chromebook to your home network follow these instructions:


Step #1:

Click on the WiFi signal at the bottom of your screen.




Step #2:

In the dropdown menu you will see available wifi networks. A lock next to a network means that network requires a password to join.




Step #3:



Make sure your WiFi switch is toggled **on**.

If you are connected to a network you will see a green message beneath the network. If you are connected but still can't get online, you may need to sign permissions or you may need to refresh your screen.

To refresh your screen, close and re-open your browser.



If you don't have your own WiFi, **XFINITY** has free WiFi hotspots throughout the District and State to provide access to as many people as possible during school closures.

Click on the network you want to join.

If there is no lock icon next to the network then you don't need a username or password. Your computer should automatically connect.

